

VX120P/150P/170P(-QM57)

User's manual rev. 0.0

Preliminary

I.P.S. Sistemi Programmabili srl

Via Piave 54
21040 Caronno Varesino (VA) Italy
Tel. +39 0331 980669
Fax +39 0331 980476

URL: <http://www.ipscomputers.com>
Technical support and service: support@ipssistemi.com



Copyright 2011. All rights reserved.

About this manual

This manual is applicable to the equipments:

- VX120P-QM57 code number C654.xxxxxxxxxx (Panel PC with 12.1" LCD)
- VX150P-QM57 code number C754.xxxxxxxxxx (Panel PC with 15" LCD)
- VX170P-QM57 code number C854.xxxxxxxxxx (Panel PC with 17" LCD)

where x means configurations and options according to ordination code.

The identification code number is on the back side of the chassis.

In the continuation of this manual these equipments are called "Panel PC".

The motherboard user's manual is provided with the Panel PC.

The motherboard is CP100-NRM model.

If problems occur contact I.P.S. technical support.

The user's manuals are a part of the product.

Take care of these manuals and refer to them in the future for information about the Panel PC and the motherboard.

Target group

This manual has been written for the following readers:

- Installation engineers who perform the mechanical and electrical installation of the VX120P/150P/170P(-QM57) Panel PC.
- Service and maintenance engineers who install upgrade or spare parts.
- OEM (Original Equipment Manufacturer) users.

Timetable of the revisions

Rev.	Description	Applicable	Date
0.0	Preliminary (subject to change)	VX120P/150P/170P (-QM57) Rev. 0.0	08/11/2011

Contents

1	General notes	6
1.1	Safety guidelines.....	6
1.2	Correct usage and general safety information	7
1.3	Battery	9
1.4	Application permitted.....	9
1.5	Applications not permitted	10
1.6	Exclusion of Liability	10
1.7	Copyright.....	11
1.8	Software license agreement for end user	11
1.9	Warranty	12
1.10	Procedure for repairing the products:	12
1.11	Electromagnetic compatibility and safety.....	13
2	Unpacking	14
3	General description	15
3.1	Features.....	15
3.2	Description	15
4	Installing.....	20
4.1	Permitted mounting positions	21
4.2	Panel mounting with clamps.....	22
5	Connecting.....	26
5.1	Connecting 115/230Vac power supply	26
5.2	Uninterruptible AC power supply (UPS)	27
5.3	Connecting 24Vdc power supply (option)	28
5.4	Connecting the serial I/O ports.....	30
5.5	Connecting the shields.....	30
5.6	Equipotential bonding.....	31
5.7	Connecting external keyboard/mouse	31
5.8	Connecting USB devices.....	32
5.9	Connecting the Ethernet (LAN) port	33
5.10	Connecting audio devices	33
5.11	Connecting the monitor display	33
5.12	Connecting a VGA monitor.....	34
5.13	Connecting a DVI monitor	34
6	Switching on.....	35
6.1	Power on.....	35
6.2	Power off.....	36
6.3	Power button.....	36
6.4	BIOS setup.....	36
7	Operator controls	37
7.1	Touchscreen control.....	37
8	Technical specifications	38

8.1	Mechanical specifications.....	38
8.2	Climatic conditions	40
8.3	Power consumption.....	41
8.4	Internal Power supply 115/230Vac.....	42
8.5	Internal Power supply 24Vdc (option).....	43
8.6	Motherboard.....	45
8.7	RAM.....	45
8.8	Hard disk.....	46
8.9	Hard disk RAID	46
8.10	Compact Flash disk.....	47
8.11	Hard disk 2,5" + Compact Flash.....	48
8.12	Serial ports.....	49
8.13	Keyboard/mouse interface	49
8.14	USB port	50
8.15	Ethernet (LAN)	50
8.16	Audio controller	50
8.17	Graphics controller	51
8.18	LCD display.....	51
8.19	Touchscreen	53
9	Maintenance	55
9.1	General.....	55
9.2	Spare parts	55
9.3	Replacing the motherboard.....	55
9.4	Replacing the Compact Flash disk (CF)	57
9.5	Replacing the 2,5" hard disk	58
9.6	Replacing the power supply	59
9.7	Replacing the battery	60
9.8	Checking the CPU fan.....	61
9.9	Checking the Power Supply fan	61
9.10	Checking the chassis fan	61
9.11	Cleaning the fan filter	61
9.12	Cleaning the display.....	62
10	Troubleshooting.....	63
10.1	Troubleshooting procedure	63
10.2	Troubleshooting check list.....	63
11	Decommissioning	65
11.1	Disposal	65

1 General notes

1.1 Safety guidelines

This manual contains notices, which you should observe to ensure your own personal safety as well as to protect the Panel PC and connected equipment. These notices are marked as follows.



Danger

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



Warning

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Caution

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

Caution

Used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

Notice

Notice indicates notes on use of equipment and useful practical tips. Indicates also that unwanted events or status can occur if the relevant information is not observed

Draws your attention to particularly important information on the product, using or handling the product



This symbol reminds you of the possible consequences of touching electrostatic sensitive components.



This symbol reminds you the high temperature of a device or a Panel PC component.

1.2 Correct usage and general safety information



Warning

The Panel PC is intended for professional use only in an industrial environment.

The information contained in this manual is intended for technical staff who has adequate knowledge of the structures hardware and software and of the operation of personal Panel PCs.

The equipment must be installed, maintained and serviced only by qualified or instructed personnel in accordance with safety standards. The Panel PC may only be used for the “Application permitted” specified in this manual.

Appropriate transport and appropriate storage, installation and assembly as well as careful operation and maintenance are required to ensure that the product operates safely.

Caution

For correct usage of the Panel PC observe the following indications:

- Read carefully this manual and that of the motherboard before installing or using the Panel PC.
- If on removing the Panel PC from its packaging you observe obvious signs of damage do not connect it and inform the I.P.S. technical service (see the “Procedures for repairing the products” paragraph).
- Make sure that the operating conditions (temperature and humidity) are as indicated in the “Climatic conditions” paragraph later in this manual.
- Make sure that the supply voltage falls within the range indicated in the specifications.
- Before removing the Panel PC back cover switch the Panel PC OFF and detach the power cord. Do not use the Panel PC without the back cover installed. An electrical shock hazard exists. The back cover also functions as an EMI shield.
- While Panel PC working the back cover has to be fasten to the chassis.

- Before working on the rear part or inside the Panel PC the person performing the operation must discharge any static electricity by touching a metal part connected to the ground. Perform work in a static safe environment. Check the 5Vsb (5V stand-by) is off (turn off the input power then disconnect the power cord).
 - When making any interface connections to the Panel PC (expansion cards, serial ports, PS/2 keyboard and mouse, etc.) switch the system off. Only the connection of the USB ports can be performed with the Panel PC on.
 - Avoid thermal shocks to the Panel PC.
 - Do not obstruct the ventilation slits.
 - Avoid turning the system ON and OFF frequently. After shutting the system OFF, do not turn it ON back again until the hard disk has come to a complete stop (takes about 20 seconds).
 - Always use the proper power down procedures as required by your Operating System such as "Shut Down" command in WinXP.
 - The user should have considerations for data safety and integrity on the hard disk drive or solid state disk (flash) and perform data backup. Standard hard disks are not suitable to operate 24hours x 7 days continuously.
 - During a thunderstorm do not make connection and do not touch power supply and data transmission cables.
-

**Caution**

If the LCD display glass breaks, avoid contact with the liquid that may leak out. If the liquid crystal material leaks from the panel, it should be kept away from eyes or mouth. In case of contact it must be washed away immediately and thoroughly with water then consult a doctor. In case of contact with hands, legs or clothes, it must be washed away immediately and thoroughly with water and soap.

**Warning**

The power cord (115/230Vac version) must be connected to an outlet with protective earthing. Failure to follow this warning could result in severe electrical shock.

1.3 Battery

The Panel PC contains a lithium battery. The batteries must be replaced by an authorized qualified technical only.

**Warning**

Danger of explosion and harmful material emission if lithium battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. The battery module contains lithium. Do not attempt to dispose of it in a fire or incinerator, do not overheat up to 80°C, do not short-circuit, do not invert poles, do not disassemble it: the battery may explode.

Don't try to recharge the lithium battery, the battery may explode.

Don't allow the battery to come in contact with water.

Always follow regulations in your area for lithium battery disposal.

1.4 Application permitted

The Panel PC use is permitted as stationary equipment for building-in for indoor applications in an industrial environment.

The equipment is suitable for use as Human Machine Interface (HMI).

Because of the variety of uses for the Panel PC those responsible for the application and use of this Panel PC must satisfy themselves that all necessary steps have been taken to assure that each application and use meet all performance, safety requirements, including any applicable laws, regulations and standards. Following the results of a risk analysis, additional protection equipment on the machine or the system is necessary to avoid endangering persons.

1.5 Applications not permitted

The Panel PC has not been designed and not been tested and so it is not authorized for use different from the one described in "Application permitted". Particularly, but not limited to them, the Panel PC is not authorized for the following applications:

- use in an atmosphere potentially explosive;
- use for radiology and medical purpose;
- use on ships, aircraft and railways and other transports;
- use in life support devices or systems;
- use outdoor;
- use in all the application or environment where the EMC and SAFETY standards cited on the "Electromagnetic compatibility and safety" paragraph in this manual are not applicable or not satisfactory that is where other or additional standards must be applied.

1.6 Exclusion of Liability

I.P.S. Sistemi Programmabili reserves the right to make modifications to its products without warning to improve features or design.

The information contained in this document is supplied only as reference for the use of the product itself.

I.P.S. accepts no responsibility for the use of the information contained in this document or the products cited in it.

Any reference to the compatibility with a PC (personal computer) does not warrant that any kind of software, created for a PC, works well with the Panel PC without fitting and/or modifying it.

While reasonable efforts have been made to assure the accuracy of this document, I.P.S. assumes no responsibility or liability for any errors, inaccuracies or omissions that may appear in this manual, including the products and software described in it. However, the information in this document is reviewed regularly and any necessary corrections are included in subsequent editions.

Because of the variety of uses for the Panel PC described in this manual, those responsible for the application and use of this Panel PC must satisfy themselves that all necessary steps have been taken to assure that each application and use meet all performance, safety requirements, including any applicable laws, regulations and standards.

The user should have considerations for data safety and integrity on the storage devices (e.g. hard disk drive) and perform data backup.

I.P.S. accepts no responsibility for damage suffered by the User (including, but not limited to this, that for loss of commercial profits, and interruption of activity and similar) which derive from the data integrity on the storage devices.

1.7 Copyright

This document may contain references to or information concerning products back covered by copyright or patent.

No right concerning these products is however conceded through this manual.

All trademarks showed in this manual are the property of their respective holders.

All the rights of this document are reserved.

1.8 Software license agreement for end user

The Panel PC contains intellectual property, i.e. software programs, which are supplied under license to be used by the End User, who is any Panel PC owner or user.

The Panel PC could contains parts of programs distributed under license by Microsoft Corporation and other brands including software, which belongs to I.P.S. Sistemi Programmabili.

The transfer of the Panel PC does not constitute a sale of this intellectual property. The End User must not copy, disassemble or decompile the software programs.

The programs are supplied to the End User as they are, with no guarantee of any sort, either implicit or explicit, including but not limiting the guarantees of adaptability to a particular task.

The End User is entirely responsible for the program quality and performance.

I.P.S. Sistemi Programmabili and its suppliers are not responsible for damage suffered by the End User (including, but not limited to this, that for loss of commercial profits, and interruption of activity and similar) which derive from the supply, use or performance of the software programs.

These provisions are subject to Italian law. If one or more provisions are in contrast with the laws in force they should be considered not valid, the remainder however remaining completely valid and operative.

No modification to these provisions is valid unless released in writing by an authorized representative of I.P.S. Sistemi Programmabili srl.

1.9 Warranty

I.P.S. Sistemi Programmabili guarantees its products for 12 (twelve) months from the date they leave the factory. The warranty is limited to repair or replacement, at our factory, of the parts which are not working because of manufacturing defects and does not back cover products which have been tampered with, are missing components, have been incorrectly repaired or have been used differently from the specified conditions of use. Damage caused by electrical phenomena, including lighting and electric and electrostatic discharges in general and the materials provided to protect the circuits (e.g. fuses etc.) are excluded from the warranty.

Moreover the warranty does not back cover products from which the product identification marks have been removed or altered in some way.

Follow the procedure in the next paragraph to send the defective products. I.P.S. Sistemi Programmabili will repair them after having ascertained that the warranty conditions apply. If the conditions for applying the warranty do not apply the product will still be repaired, but debiting the repair costs.

The material replaced remains the property of I.P.S. Sistemi Programmabili.

1.10 Procedure for repairing the products:

Contact technical after-sales service

by fax at +39 0331 980476

by email at support@ipssistemi.com.

Report what type of service is required, model and code number of the product to be repaired and person to be contacted.

I.P.S. after-sales service will contact you to settle ways and means for the service. Any dispatch must be authorized from I.P.S. by written communication and products sent carriage free.

Products that are not authorized to be sent will not be accepted for repairing.

1.11 Electromagnetic compatibility and safety

The VX120P/150P/170P(-QM57) industrial Panel PC, used as intended in the user manual, conforms to the following standards:

Electromagnetic compatibility

EN61000-3-2	Current Harmonics limits
EN61000-3-3	Limitation of voltage fluctuation and flicker
EN61000-6-2	EMC Generic Immunity Standard – Industrial
EN61000-6-4	EMC Generic Emission Standard – Industrial
EN55024	Immunity requirement – ITE
EN55022	Radio Disturbance requirement – ITE

Notice

This is a Class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.

The domestic environment is an environment where the use of broadcast radio and television receivers may be expected within a distance of 10m of the apparatus concerned.

Safety

EN60950	Safety of ITE (Information Technology Equipment) Equipment for building-in.
---------	--

2 Unpacking

Unpack and visually inspect the Panel PC for damage, which may have occurred in shipment.

Retain all packing material and shipping documentation in case reshipment becomes necessary.

If damage has occurred in shipment, notify the carrier at once to initiate a damage claim.

Caution

If on removing the Panel PC from its packaging you observe obvious signs of damage do not connect it and inform the I.P.S. technical service.

If you have inspected and checked the product and if you are in order to install the Panel PC later, put the Panel PC in its packaging with this manual and all the enclosed documentation.

Caution

Make sure that the temperature of the storehouse falls within the range indicated in the "Climatic conditions" paragraph.

3 General description

3.1 Features

- *Flat-screen Industrial Panel PC*
- *CPU Intel Core i5-520M or Celeron P4500. Chipset Intel QM57;*
- *Integrated graphics controller Intel Gen5.75;*
- *12.1" TFT color LCD 1024x768, 15" 1024x768, 17" 1280x1024;*
- *LCD with LED backlight;*
- *8 wire resistive touchscreen with RS232 interface (option);*
- *Motherboard Mini ITX;*
- *Up to 8 GB DDR3 DRAM (Dual Channel memory interface) ;*
- *2.5" Sata HDD (2 HDD RAID-1 option);*
- *IDE Compact Flash socket (option);*
- *Up to 4 RS232 serial ports (port COM4 reserved for touchscreen);*
- *4+1 USB type A connectors, USB rev. 2.0/1.1;*
- *2 RJ45 connectors for Gigabit Ethernet ports (Intel + Realtek controller);*
- *2 PS/2 style connectors for external keyboard and mouse;*
- *Line in, line out e mic. connectors;*
- *Power supply 115/230Vac 50-60Hz (24Vdc option);*
- *Front panel with IP65 level protection capabilities;*
- *IP20 rear side protection.*

3.2 Description

The VX120P/150P/170P(-QM57) is a powerful and compact Panel PC, specially designed to meet the requirements for an industrial Human-Machine-Interface.

The chassis is constructed with an aluminium front panel and steel back case. The case is designed for panel mounting.

The TFT LCD display with LED backlight provides high brightness, high contrast and long life.

The touchscreen (option) is 8-wire resistive type, which provides very good touch point resolution and long term calibration over temperature range.

Touchscreen interface requires RS232 COM port and, if present, is connected to COM4.

The Panel PC is equipped with Intel QM57 chipset and Intel Core i5-520M or Celeron P4500 processor.

The Panel PC is provided with 2,5" magnetic hard disk drive Sata.

As option it can be equipped with two 2,5" Sata HDD RAID-1.

As alternative to the magnetic hard disk and as an order option the Panel PC is provided with one or two sockets for solid state disk Compact Flash (CF).

As option it's possible to have a version with CF plus 2,5" HDD.


If compared to a magnetic disk, the solid state disk CF offers lower power consumption and improved temperature range.

The CF is easy removable opening a protection cover.

On the I/O panel of the Panel PC there are 2 PS/2 style connectors for an external keyboard and mouse , a 15-pin VGA connector, a 24-pin DVI-D connector, 4 USB type A connectors, USB rev. 2.0/1.1 compliant, up to 3 RS232 serial ports and 2 RJ45 connectors for Gigabit Ethernet ports.


A further USB type A connector is available on the front panel (except for True Flat panel version)

The Panel PC is equipped a 115/230Vac power supply or 24Vdc DC/DC converter (option).



Front view

Pos.	Description	Note
1	Led ON	it indicates the Panel PC is ON
2	Led HD	it indicates operation on HDD
3	LCD Display and touchscreen (opt.)	
4	USB connector	Behind a protection cover (except for True Flat panel version)




Connectors side view

Pos.	Description	Note
1	Equipotential Bonding screw	For earthing
2	Power supply connector	115/230Vac or 24Vdc (option)
3	Compact Flash socket	option (protected by a cover)
4	I/O panel	depends on the motherboard (see picture)
5	Power on switch	Soft power ATX (inside the hole)
6	Reserved	DB9 connector cut-out
7	Reserved	Antenna connector cut-out



I/O Panel



Upper side view

Pos.	Descrizione	Note
1	Fan filters	40x40mm.

4 Installing

Before installing the Panel PC, please read carefully the following information.

Caution

The Panel PC is permitted for indoor fixed applications only.
The Panel PC is set up for installation in a prepared recess such as in the panel of a cabinet or a console.



Warning

Disconnect all electrical power and unplug the power cord before installing the Panel PC.
Make sure the installation of the Panel PC maintains proper earthing. The Panel PC requires connection to a power source having a quite earthing.
Failure to follow these precautions may result in personal injury or damage to the Panel PC or to the components.

Caution

A power outlet provided with an earthing connection and a mains disconnect switch are required nearby and easily approachable.
The display should not be exposed to direct sun light or other strong light sources.
Make sure the ambient temperature stays within the operating temperature range as specified in the "Climatic condition" paragraph later in this manual.
Be aware of other nearby devices, which may raise the ambient temperature in the cabinet. Besides take in consideration the heating of the Panel PC itself.
Make sure there is adequate room for airflow through the chassis vent. The power supply fan cooler draw out the inside air flowing it toward the bottom side. Avoid hot air heap up in the bottom area of the Panel PC. Leave a free area all around the Panel PC: at least 20 cm on bottom side and 10 cm. from the other sides. More free area could be required by the application.

Position the Panel PC so that the air vents in the housing are not back covered by following installation.

The max. air intake temperature must not exceed the max. operative temperature provided for the Panel PC in use. Moreover the input air must be free of corrosive gas or powder.

The Panel PC weigh is indicated in "Mechanical specification". Verify that the addition of the Panel PC does not cause instability of the cabinet.

Install the Panel PC in a way it doesn't cause a potentially hazardous situation (e.g. falling down).

If required use stiffeners to reinforce the cut-out mounting.

Leave enough free room for disassemble and maintenance service

Avoid condensation inside the cabinet


The Panel PC is set up for installation in a prepared recess such as in the panel of a cabinet or a console, so that the only part accessible to the operator is the front panel, including the touchscreen (option) and the LCD. This is the use for which it is designed.

Place the screen in an ergonomic position for the operator and select a corresponding installation height.

The maximum panel thickness allowed is 5mm. The minimum suggested is 2mm.

4.1 Permitted mounting positions

The Panel PC is designed to be installed in vertical position only with a $+45^\circ / -5^\circ$ deviation in the direction indicated.



Mounting position

4.2 Panel mounting with clamps.


Use protection gloves to install the Panel PC.

Four/six (depend on the model) clamps with grub screws are provided with the Panel PC for panel mounting.




To perform the installation of the Panel PC follow these steps:


- Make a cut-out hole dimensioned as indicated in pictures (depend on the model). Make sure the area around the panel cut-out is clear.



Cut-out for VX120P-QM57 mounting (specification in mm tolerance $\pm 0.5\text{mm}$)




Cut-out for VX150P-QM57 mounting (specification in mm tolerance $\pm 0.5\text{mm}$)



Cut-out for VX170P-QM57 mounting (specification in mm tolerance $\pm 0.5\text{mm}$)


- Fit the Panel PC into the cut-out.



Fitting into the cut-out on user panel

Pos.	Description	Note
1	User's panel	
2	rear part of the Panel PC	
3	front panel of the Panel PC	


- Screw two grub screws into the holes present in each clamp, with the tips of the grub screws towards the concave side of the clamp, (this step is performed at the factory). Insert clamps into the holes present all around the Panel PC.



Inserting clamps into holes all around the Panel PC

Pos.	Description	Note
4	Holes for clamps coupling	Around the Panel PC there are 4/8 on the upper/lower side and 4 on the left/right side.
5	Clamp	Panel PC panel mounting needs 4/6 clamps.

- Screw grub screws clockwise.



Screw grub screws

The recommended tightening torque for the grub screws is 0.3 Nm (30 cNm).

Pos.	Description	Note
6	Grub screws	To fasten the Panel PC to the panel, screw grub screws clockwise.

Once the Panel PC is fitted into the housing and the grub screws tightened, the gasket on the edge of the frame adheres to the panel and it provides a seal against infiltration of liquids and/or dust.

Caution

The class protection of the front is only obtained by correctly fastening the Panel PC to the panel. Besides the cover of the USB connector must be closed and the screw well tighten. The gasket forms a compression type seal, do not use other sealing compounds.

Be careful not to damage the sealing gasket when installing the Panel PC. A damaged seal may result in damage to the Panel PC and other panel components due to a leaking seal.

Be sure the cabinet panel is planar and it does not bend itself when the screws grub of the clamp are tightened. If the panel bent the gasket does not press well and the sealing is not guarantee.

If necessary use stiffeners to reinforce the cut-out on the panel.

When the USB cover panel is open during an USB device connection, the class protection is downgraded.

5 Connecting

Before connecting and switching on the Panel PC, please read carefully the following information.

Caution

During a thunderstorm do not make connection and do not touch power lines and signals cables.

5.1 Connecting 115/230Vac power supply

The Panel PC is equipped (except for different order option) with a 115/230Vac input power supply provided with standard IEC60230 3 pin C14 connector.

The power supply input will accept 115/230Vac auto-ranging.

A standard IEC60320 3 pin C13 power cord is provided for plug-in to an outlet having a protective earthing.



Warning

The power cord must be connected to an outlet having a protective earthing. Failure to follow this warning could result in electrical shock. Since the Panel PC does not have a power switch, turning off and completely disconnecting power require pulling the power plug. A power outlet provided with a protective earthing and a mains disconnect switch are required nearby and easily approachable.

Notice

To prevent an unintentional unplugging of the power plug from the Panel PC, we recommend fastening the power cord.

The internal power supply has protection against overcurrent by means of a fuse.



Warning

Do not try to disassemble the power supply unit to replace the fuse or other parts.

If a failure occurs on the power supply, the whole power supply unit must be replaced with an equal or equivalent approved spare part.

Inside the Panel PC there is an insulated AC\DC converter (power supply) which converts the input voltage into the ATX standard low voltages needed for the Panel PC to operate (see "Internal Power supply 115/230Vac" paragraph).

The 0V (GND) of the internal supply ATX is connected to the metal frame and then to the Equipotential Bonding screw for earthing.

When the Panel PC is connected, through any not insulated I/O port, (e.g. serial, or other port) to another equipment also with GND connected to earth both of them must be connected to the same earth point to avoid circulation of current because of the difference of potential between earth points.

5.2 Uninterruptible AC power supply (UPS)

The paragraph indications are referred to a use of the Panel PC connected to an uninterruptible AC power supply (AC UPS).

Due to legal regulations finalized to reduce the reactive power in the electrical networks, the Panel PC power supply has a built-in active PCF (Power Factor Correction). The active PFC needs a sinusoidal wave input voltage.

Caution

The uninterruptible AC power supply (UPS) with non sinusoidal wave can damage the power supply with active PFC.

Be careful the UPS, if connected to VX120P/150P/170P(-QM57) with active PFC, supplies a sinusoidal wave output voltage during normal and back-up mode.

5.3 Connecting 24Vdc power supply (option)

The Panel PC can be provided (as an order option) with an isolated DC/DC converter with 24Vdc input. The DC/DC converter has a forced-air cooling by fan. The user must supply the 24Vdc by connecting 2 conductors to the connector of the DC power supply.

The cross-section of the conductors shall be adequate for the supplied current (see "Internal Power supply 24Vdc") and must be sufficiently oversized so that in case of a short circuit on the Panel PC no damage can be caused by the cable.



Warning

The insulation towards the main voltage depends on the external power supply to the Panel PC. The Panel PC must be supplied by a limited power source according to EN60950. Use a switching power supply protected against overcurrent which complies with the requirements of safety extra low voltage (SELV) which conforms to the safety standard EN60950 or equivalent.

It's recommended using a power supply reserved for the Panel PC.

None of the wiring terminals is designed to be connected to parts at hazardous voltage.

The wiring from the external power supply to the Panel PC must comply with the requirements of safety extra low voltage (SELV).

Caution

The terminal on the 24Vdc input power supply is not suitable to switch the Panel PC ON and OFF. Use a power switch on the external power supply to switch ON-OFF the Panel PC.

Notice

The external power supply must provide the inrush current required by the internal DC/DC converter at power-up without enter self protecting mode otherwise the system start up is not guaranteed (see "Internal Power supply 24Vdc" paragraph).

The internal DC\DC converter is protected against overcurrent by a fuse.



Warning

Do not try to disassemble the power supply unit to replace the fuse or other parts. If a failure occurs on the power supply, the whole power supply unit must be replaced with an equal or equivalent approved spare part.

The Panel PC must be connected to earth by means of a conductor of suitable cross section connecting the Equipotential Bonding screw on the chassis to the quiet earth point.

The 0V (GND) of the internal supply ATX is connected to the metal frame and then to the Equipotential Bonding screw for earthing.

When the Panel PC is connected, through a not insulated I/O port, (e.g. serial or other port) to another equipment also with GND connected to the earth both of them must be connected to the same earth point to avoid circulation of current because of the difference of potential between earth points.

5.4 Connecting the serial I/O ports.

The Panel PC can be equipped with up to three RS232 serial ports according to order options .

Refer to the motherboard user's manual for further information.

- Shielded cable must be used for the RS232 serial ports. Inside the cabinet the cables of the serial ports must be kept separate from the power signal cables.
- If RS485 port is used, cable must be of twisted pair type. The positive signal must be twisted with the respective negative signal (e.g. D+ with D-). Moreover if one is not sure that the common mode voltage will remain within the maximum values allowed of $-7V$ or $+12V$ with respect to GND the GND reference signal connection must also be made. If there is connection between distant appliances (e.g. different buildings or even different departments in the same building) a possible difference of voltage between the earth must be considered (even momentarily because of faults or disturbances) which might make a high current circulate in the GND reference signal and consequently damage the Panel PC or the connected appliance or the connection cable. In these cases it is recommended to use an external RS422/RS485 insulated adapter connected to a RS232 port.

Caution

Do not connect or disconnect the cables of the serial ports with the Panel PC or the external apparatus switched on.

Notice

The maximum length of the RS232 connection is 15m.

5.5 Connecting the shields

The braids (shielding) of the shielded cables have to be connected to the Panel PC, directly to the metal casings of the serial port connectors. Those metal casing are connected to the chassis and to the internal earth point. For proper shielding, for high frequencies, the shield has to be connected at both ends to ground reference. If the shield is connected to earth on both ends, care must be taken to avoid circulating currents.

5.6 Equipotential bonding

Low impedance connections toward earth reduce the interference current from external power supply cables, signal cables and peripheral connection cables.

The Panel PC equipotential bonding is located near the input terminal of the power supply.

Between different parts of an electric plant it makes electrical potential that, in some cases, can generate high equalization currents. It occurs for example when both sides of the shield of a cable are grounded at different point of the plant. Potential differences can be for example different power supply.

If necessary is possible to reduce the potential difference by laying the equipotential bonding cable as the electronic devices function properly.

For the equipotential bonding see as follow:

- If two system parts are connected trough shielded cable and their shields are connected both sides to ground or protection conductor, the following must be observed: the impedance of the equipotential bonding cable should be having an impedance max. of 10% of the shield impedance.
- The section of the equipotential bonding cable has to be sized for the maximum compensation current present. The cross-section in any case should be not less than 5mm² and bigger size is better.
- Use equipotential bonding cables made of copper or galvanized steel. Connect the cables to ground over a wide area. Protect the ground or the protective conductor against the corrosion.
- The surface area between the signals cable and the equipotential bonding cable should be as small as possible.

5.7 Connecting external keyboard/mouse

Two PS/2 style connectors allow the connection of an external keyboard and mouse. These connectors are on the I/O panel. The mouse connector is green while the keyboard one is violet.

Notice

If commercial PS/2 peripheral are used, the EMC immunity often is suitable for office use only. For the start up and for the assistance these devices are enough.

Moreover for industrial use of industry-standard devices are recommended. Furthermore proper EMC practice must be considered in cabling the external keyboard or mouse.

Caution

Do not connect or disconnect the external keyboard or mouse when the Panel PC is switched on. Switch off input power before connecting or disconnecting the keyboard or the mouse.

5.8 Connecting USB devices

The Panel PC is equipped with four USB type A connectors on the I/O panel.

USB port name on the label is for reference only.

USB ports are hot plugging that is USB connectors can be plugged or unplugged even if the Panel PC is switched on.

A further USB connector is available on frontal panel covered by a little door (except for "True Flat" panel version).

The USB ports are compliant with USB rev. 2.0/1.1. The USB external devices (e.g. printers) require a specific software driver. Follow the manufacturer's instructions to install USB devices.

The total max. current, for external USB devices, absorbed from the USB connectors must not exceed 0.5A for each connector. Furthermore the total power (5V) absorbed must be within the limit (for expansion devices) specified in the "Internal power supply" paragraph in this manual.

Refer to the motherboard user's manual for further information.

Notice

Use a cable 5m max long to connect an external USB device to an USB connector on the I/O panel.

Use a cable 4m max long to connect an external USB device to the USB connector on the front panel.

After having unplugged a USB device wait for at least 10 sec. before to plug it in again or plug in a different one.

If commercial USB type is used, the EMC immunity often is suitable for office use only. For commissioning and servicing this devices are enough. Moreover for industrial operation industry-standard devices are recommended.

Caution

If the protection door that cover the USB interface on front panel is opened to connect a USB device, the protection grade is downgraded.

5.9 Connecting the Ethernet (LAN) port

The Panel PC provides two Gigabit Ethernet ports (10/100/1000).

Two RJ45 connectors on the I/O panel are provided for the connection.

One LAN is by an Intel controller and the other one by a Realtek controller.

LAN number on the label is for reference only.

LAN number on the OS (e.g. WinXP) depends on the detection when installing drivers.

Use approved cables CAT.5E or better for connection to Gigabit Ethernet.

The WinXP device drivers for the Ethernet controller are in the motherboard DVD-ROM. Refer to the motherboard user's manual for further information.

5.10 Connecting audio devices

On the I/O panel there are 3 connectors (line out, line in e mic). These connectors are provided for the connection of speakers, microphones and other audio devices.

The WinXP device drivers for the audio controller are in the motherboard DVD. Refer to the motherboard user's manual for further information.

5.11 Connecting the monitor display

The computer motherboard has three types of video interface for display.

1-LVDS interface for internal LCD panel (main display)

2-VGA interface for external CRT/LCD analog monitor


3-DVI-D interface for external LCD digital monitor

The display interface is under Bios control until WinXP boots (WinXP logo included) afterwards the Intel Graphics Drivers keep the control.

The Intel Graphics Drivers are in the motherboard DVD.

The Bios Setup provides options for the display.

The picture shows the Setup for VX170P-QM57 with LCD 17" 1280x1024.



For VX120P-QM57 and VX150P-QM57 the "LCD Panel Type" setting is [Type 3 1024x768].

By the Intel Graphics Drivers it's possible to select the Graphics Properties for the display. The display are named:

Built in Display = internal LCD panel

Monitor = external monitor with VGA interface

Digital Display = external monitor with DVI interface

The Intel Graphics Drivers detect if a VGA or a DVI monitor is connected to the computer and adjust the Graphics Properties options.

The Panel PC allows display on internal LCD panel and, at the same time, on one external monitor (VGA or DVI) by the Graphics properties "Clone Displays".


5.12 Connecting a VGA monitor

The computer supports a connector for an analog monitor standard 15 pin VGA (blue color) placed on I/O panel.

Notice

The VGA monitor can be connected to the Panel PC by a standard 2m. VGA cable

A plug and play VGA monitor could be detected as "PnP Monitor" if only the VGA cable is full pin type (pin 9 included). Otherwise it is detected as "Default monitor". The following picture shows the Graphics Properties for the LCD+Monitor VGA.




5.13 Connecting a DVI monitor

The computer supports a connector standard 24 pin DVI-D (white color) placed on I/O panel.

The DVI monitor must be connected to the computer before boot time.

The following picture shows the Graphics Properties for the LCD+Monitor DVI.



6 Switching on

Caution

Ensure that there is no condensation on or inside the Panel PC when transporting it at low temperature or when it is exposed to temperature fluctuations.

Before switching it on, the Panel PC must be brought to room temperature slowly. In case of condensation, wait approximately 12 hours before switch the Panel PC on.

6.1 Power on

The power supply inside the Panel PC is ATX standard. The power on sequence follows the ATX specifications.

- The 5Vsb is a stand-by output that is active whenever the 115/230Vac power input (or 24Vdc opt.) is present . 5Vsb provides a power source for circuits that must remain operational when the main DC outputs are in disable state (e.g. soft power control).
- When the power button is pressed the main DC outputs are enabled and the Panel PC starts the boot sequence.

If the “Restore AC Power Loss” in the BIOS Setup is set ON, the power on sequence is executed automatically (without pressing the power button) whenever the power input is switched on.

An Auto power-on jumper on the motherboard can bypass the BIOS Setup (default). In this case isn't necessary to set to ON “Restore on AC Power Loss”.

If the computer is switched on by power input then the boot starts about 5 seconds after power on.

Notice

Whenever the battery loses power, system settings (BIOS Setup) stored in CMOS RAM are cleared. If the Auto power-on jumper isn't installed you must press the power button to switch the Panel PC on (soft power).

Caution

Detach power plug before to open the Panel PC.
5Vsb could be active!

6.2 Power off

Power off can be executed as follow:

- Execute the shut down command (WinXP).
- Switch off the power input.

Caution

We recommend executing and terminating proper shut down procedure before switching off the power input otherwise data may be lost.

After the power input is switched off you must wait about 15 seconds before switch it on again otherwise the computer could not restart.

Time is needed to allows 5Vsb capacitors discharge.

6.3 Power button

The power button (soft power) is available on the I/O panel. A stylus or similar is needed to push the button.

Pressing the button switches the system between ON and Soft OFF, depending on the BIOS or OS settings.

If the computer is Soft Off condition pressing the button switches the system ON.

6.4 BIOS setup

Some configuration settings are stored in a battery backed-up static RAM as part of the BIOS setup.

Notice

We recommend you keep a note of the Setup settings. You will need to reset some settings if the battery that provides power for the CMOS RAM will get exhausted.

To enter Bios Setup you need a keyboard.

Read carefully the motherboard user's manual before to attempt to change BIOS Setup.

The Panel PC is provided with BIOS setup setting for manufacturer tests.

If operating system is installed by user refer to the pertinent documentation.

7 Operator controls

7.1 Touchscreen control

The touchscreen display is sensitive to touch and it shows some application-specific elements like e.g. a button.

Pushing the button by finger, the system will execute the corresponding function as provided by the application software.

Caution

Always touch one point on the touchscreen and not several points at one time. Otherwise unintended reactions can occur.

Caution

If the touch point and the activated action are not corresponding the touchscreen can be not calibrated and unintended reactions can occur.

If necessary calibrate the touch using an external mouse.

If the problem is not resolved do not use the touchscreen.

Caution

The touchscreen is active even if the display shows anything (black screen) due for example of a LCD lamp damage.

If you push the touchscreen in this condition unintended reactions can occur.

In these following situations the touchscreen must not to be touch:

- During booting operation and until the boot process is completed.
- When plugging or unplugging USB devices.

Caution


The touchscreen requires only a light strength to work.

Do not push strongly on the touchscreen especially if you are using a plastic pen.


8 Technical specifications

8.1 Mechanical specifications


Front panel:	aluminium
Back case:	steel
Display window:	Touchscreen or transparent plastic sheet
Dimensions:	see drawings
Weight:	VX120P-QM57 approx. 5,5 Kg (depends on the configuration) VX150P-QM57 approx. 6,5 Kg (depends on the configuration) VX170P-QM57 approx. 8 Kg (depends on the configuration)



VX120P-QM57 dimensions (all specification in mm. $\pm 0.3\text{mm}$)



VX150P-QM57 dimensions (all specification in mm. $\pm 0.3\text{mm}$)



VX170P-QM57 dimensions (all specification in mm. $\pm 0.3\text{mm}$)

8.2 Climatic conditions

Operating temp.: 0 to 45°C;

Storage temp.: -20 to +60°C.

Relative Humidity: 10 to 90% at 25°C without condensation.

Notice

It is prohibited to apply sunlight or fluorescent light to the display during the store.

It is highly recommended to store the Panel PC with temperature from 0 to 35°C and relative humidity of less than 70%.

The operating and storage conditions are dependent on the combination of the subsystems. The max temperature permitted for the CPU can reduce the max operating temperature (see the “motherboard” paragraph).

The LCD has not the same display characteristics over full temperature range.

Refer to “LCD” paragraph for further information.

The operating temperature must be measured inside the rack or cabinet where the Panel PC is installed.

The Panel PC can operate up to max. operating temperature under the following conditions:

- The factory-approved heat sink with cooling fan is installed on the CPU and well operating.
- The fan on the power supply and on the chassis are well operating.
- The maximum air inlet temperature for the Panel PC must not exceed the max operating temperature.
- The maximum case temperature of the Processor is not exceeded (see the “Motherboard” paragraph).
- Power absorbed by expansions (e.g. USB) is less than 10W.

Notice

Make sure there is suitable room for airflow through the Panel PC chassis vent.

The power supply fan cooler draw out the inside air flowing it toward the bottom side. Avoid hot air heap up in the bottom area of the Panel PC.

8.3 Power consumption

The following table reports the typical input power consumption for some Panel PC model. The data doesn't include the power consumption of expansions and peripherals connected to the Panel PC (e.g. USB,PS/2 etc.)

Model	Power supply	Processor	Memory	HD (note 1)	Input power (typ.)
VX120P	230Vac	Intel Celeron P4500	1x2GB DDR3	1 x 2,5"	59W
VX120P	24Vdc	Intel Celeron P4500	1x2GB DDR3	1 x 2,5"	55W
VX120P	230Vac	Intel Core i5-520M	1x2GB DDR3	1 x 2,5"	69W
VX120P	24Vdc	Intel Core i5-520M	1x2GB DDR3	1 x 2,5"	65W
VX150P	230Vac	Intel Celeron P4500	1x2GB DDR3	1 x 2,5"	57W
VX150P	24Vdc	Intel Celeron P4500	1x2GB DDR3	1 x 2,5"	53W
VX150P	230Vac	Intel Core i5-520M	1x2GB DDR3	1 x 2,5"	67W
VX150P	24Vdc	Intel Core i5-520M	1x2GB DDR3	1 x 2,5"	63W
VX170P	230Vac	Intel Celeron P4500	1x2GB DDR3	1 x 2,5"	64W
VX170P	24Vdc	Intel Celeron P4500	1x2GB DDR3	1 x 2,5"	59W
VX170P	230Vac	Intel Core i5-520M	1x2GB DDR3	1 x 2,5"	74W
VX170P	24Vdc	Intel Core i5-520M	1x2GB DDR3	1 x 2,5"	69W

Note 1: power consumption of HD could be different depending on the model.

Notice

The heat dissipation of the Panel PC itself have to be considered for the choice of a cabinet or a case where the Panel PC should be installed inside

The external power supply which provides 24Vdc to the Panel PC must be over dimensioned in comparison to the power on the table.

8.4 Internal Power supply 115/230Vac

Type: ATX.
 Input voltage: 115/230Vac $\pm 10\%$ auto-range.
 Input frequency: 50-60Hz.
 Input current: 4A (rms) for 115Vac / 2A (rms) for 230Vac.
 Efficiency: 68% min.
 MTBF: 100.000 hours at full load at 25°C (fan not include d).
 Certifications: UL, CSA, TUV, CE.

Output power: up to 150W (at 25°C)

Output voltage (dc)	Output current (max)	Tolerance
+3.3V	12A	5%
+5V	12A	5%
+12V	10A	5%
-12V	0.3A	10%
+5Vsb (stand by)	2.0A	5%

Notice

The total output power on +5V & +3.3V is **80W** max.

The total output power on +5V & +3.3V & +12V is **135W** max.

The total power available for expansions (e.g. USB) is **10W**.

Inside the Panel PC the common (0V) of the output voltages is connected to the metal frame.



Warning

The power cord must be connected to an outlet having a protective earthing.

Failure to follow this warning could result in electrical shock.

Since the Panel PC does not have a power switch, turning off and completely disconnecting power, 5Vsb included, require pulling the power plug.

8.5 Internal Power supply 24Vdc (option)

Type: ATX.
 Input voltage: 18 to 30Vdc, nominal 24Vdc.
 Input current: 14A (rms) for 24Vdc.
 Inrush current: 20A at nominal input, 25°C cold start.
 Efficiency: 75% min at nominal input and rated output.
 MTBF: 100.000 hours at full load at 25°C (fan not included).
 Standards: UL, CSA, TUV, CE.

Output power: up to 150W (at 25°C)

Output voltage (dc)	Output current (max)	Tolerance
+3.3V	12A	5%
+5V	12A	5%
+12V	10A	5%
-12V	0.3A	10%
+5Vsb (stand by)	2A	5%

Notice

The total output power on +5V & +3.3V is **80W** max.

The total output power on +5V & +3.3V & +12V is **135W** max.

The total power available for expansions (e.g. USB) is **10W**.

Inside the Panel PC the common (0V) of the output voltages is connected to the metal frame.



Warning

The insulation towards the main voltage depends on the external power supply to the Panel PC. The Panel PC must be supplied by a limited power source according to EN60950. Use a switching power supply protected against overcurrent which complies with the requirements of safety extra low voltage (SELV) which conforms to the safety standard EN60950 or equivalent.

It's recommended using a power supply reserved for the Panel PC. None of the wiring terminals is designed to be connected to parts at hazardous voltage. The wiring from the external power supply to the Panel PC must comply with the requirements of safety extra low voltage (SELV).

Caution

The terminals on the 24Vdc input power supply are not suitable to switch the Panel PC ON and OFF.

Use a power switch on the external power supply to switch ON-OFF the Panel PC.

Notice

The external power supply must provide the inrush current required by the internal DC/DC converter at power-up without enter self protecting mode otherwise the system start up is not guaranteed.

8.6 Motherboard

The Panel PC is provided with a Mini ITX motherboard with Intel QM57 chipset and Intel Core i5-520M or Celeron P4500 processor.

The processor requires a heat sink with fan to operate. Furthermore the motherboard provides a hardware monitoring for CPU temperature and fan speed. The hardware monitor works only with special software for WinXP supplied with the motherboard DVD.

We recommend do not exceed +85°C for CPU temperature.

Caution

The motherboard must work only with the (factory-approved) heat sink installed on the CPU and the fan working.

Refer to the motherboard user's manual for further information.

I.P.S. Sistemi Programmabili reserves the right to change the motherboard model without warning to update features or design.

8.7 RAM

- | | |
|----------------------|---|
| System Memory | <ul style="list-style-type: none">• Two 204-pin SODIMM sockets• Supports 800/1066MHz DDR3 SDRAM (PC3-6400/PC3-8500)• Dual channel memory interface• Supports maximum of 8GB system memory• DRAM device technologies: 1GB and 2GB DDR3 DRAM technologies for x8 and x16 devices, unbuffered, non-ECC |
|----------------------|---|

The Panel PC is equipped with one or two 204pins SoDIMM 1GB, 2GB, 4GB modules.

If two modules are use they must be of the same model (dual channel).

At boot time, the BIOS find and sizes memory present in the system.

Memory over 4GB is available only by 64bit OS.

32 bit OS supports 4GB max. but, because of Video and PCI overlapping, only 3GB or less are available as system memory.

Refer to the motherboard user's manual for further information.

Caution

Switch off input power before installing/removing Dram modules

8.8 Hard disk

The Panel PC can be equipped with a 2,5" SATA Hard Disk Drive (HDD) as order option.

Hard disk auto detect must be selected and enabled on BIOS Setup (default).

Notice

To avoid hard disk failure or file loss we recommend observing the following indications.

Never turn the system off when the hard disk indicator led on front is illuminated.

After shutting the system off, do not turn it back on again until the hard disk has come to a complete stop (takes about 20 seconds).

Always use the proper power down procedures as required by your Operating System such as the Shut Down command in Win2000/WinXP.

Although there is an extremely low possibility of drive malfunction and data error, the user should provide for their occurrence. The user should have considerations for data safety and integrity such as data backup.

Standard hard disks are not suitable to operate 24h x 7 continuously. The Setup IDE adapter menu allows BIOS to be informed about the current hard disk in use. Auto detect hard disk option allows the BIOS to determine the proper settings of the drive, based on the manufacturer's information. Avoid manually enter information for a pre-formatted disk drive. If the specific cylinder, head and sector information used was different than the manufacturer's settings the system will be unable to boot the Operating System.

8.9 Hard disk RAID

The Panel PC can be equipped with two 2,5" HDD SATA RAID-1 configuration as order option.

For information about HDD RAID-1 refer to the specific user's guide.

Refer also to the motherboard user's manual.

8.10 Compact Flash disk

As an order option the Panel PC can be equipped with a solid state disk Compact Flash (CF). The CF installation is committed to the user.

The CF is an embedded solid state data storage system that electrically complies with the PCMCIA ATA standard. The CF also supports a IDE Mode that is electrically compatible with the IDE (PC/AT) interface, requiring no additional device drivers to run existing applications in a DOS Operating System.

Caution

The Panel PC supports CF in IDE Mode only (PATA).

To configure the CF in IDE Mode, the CF must be inserted in the 50 pin socket before power is switched on. Removing and reinserting the CF while the power is on will reconfigure the CF to PC Card ATA and system hang or damage may occur.

The sector size of the CF is the same as in a magnetic disk drive: 512bytes. When compared to magnetic disk drives the CF offer lower power consumption, faster seek and access times and higher reliability for increase data integrity.

Notice

Any Flash based data storage system has a limited number of erase-write cycles. In some application data files are updated very frequently. The user must verify the number of update cycles against the expected working life on the field.

CF has expected erase-writes cycles guaranteed per logical sector (reading a logical sector is unlimited). In some applications the program requires more files update than the guaranteed erase-write cycles within the expected time. In that case it is better to use an alternative disk to store those files.

The CF on the market are of different type and reliability; refer to specific characteristic indicated by the manufacturers.

The SETUP allows BIOS to be informed about the current IDE disk in use. Auto Detect Hard Disk menu allows the BIOS to determine the proper settings of the drive, based on the manufacturer's information. Avoid manually enter information for a pre-formatted disk drive. If the specific cylinder, head and sector information used was different than the manufacturer's settings the system will be unable to boot the Operating System.

The Panel PC supports one or two Compact Flash disks (as order option). A CF socket is available opening the little cover on the bottom side of the chassis. The second socket, if provided, is internal and it's available opening the cover

The CF must be in inserted into the 50 pin socket placed on the adapter board.

Caution

The socket is polarized and CF insertion is one way only requiring a light strength. If the CF does not enter into the socket please do not force, probably you inserted the CF in the wrong way.

Notice

The CF to be inserted in the Panel PC must be Compact Flash 3.0 specification or previous. The CF must be max. IDE UDMA2 or PIO Mode 4.

To allow Windows XP booting the CF must be fixed disk type.

The CF must be configured as Master IDE or Slave IDE (by jumper on the adapter board) depending on the application.

Notice

If two CF are connected as master/slave devices sharing the same IDE cable then one must be configured as Master and the other one as Slave

The use of flash disk requires the same operating rules of the hard disk (with the exception of the 20 seconds power off delay and that it is suitable for 24h x7 operating continuously).

8.11 Hard disk 2,5" + Compact Flash


The Panel PC can be equipped (as order option) with a 2,5" HDD Sata plus a CF socket.

The CF installation is committed to the user.

8.12 Serial ports

The Panel PC is equipped with four RS232 serial ports NS16C550 compatible. The COM4 serial port is reserved for the touchscreen controller (option). The DB9-M serial port connectors COM1-2 and COM3 (option) are on the I/O panel. The following table indicates the pinout of the RS232 COM1-3 connectors.

Pin	Signal	Description
1	DCD	Carrier Detect
2	RXD	Received Data
3	TXD	Transmitted Data
4	DTR	Data Terminal Ready
5	GND	signal GROUND
6	DSR	Data Set Ready
7	RTS	Request To Send
8	CTS	Clear To Send
9	RI	Ring Indicator or Reserved



Caution

Do not connect/disconnect COM cables with the Panel PC or the external apparatus switched on.

Notice

For COM port connection use a shielded cable. The max. length of the RS232 connection is 15m. The cases of the DB9-M connectors are connected by the metal chassis to the internal 0V.

The BIOS Setup provides a menu to set the serial port settings (address/IRQ). The COM1-3 labels on the Panel PC refer to the default BIOS Setup as set at the factory. If you change the serial port settings the reference could mismatch. Refer to the CPU board user's manual for further information.

8.13 Keyboard/mouse interface

Two PS/2 style connectors on the I/O panel allow connection of external keyboard and mouse. The mouse connector is green while the keyboard one is violet.

Caution

Do not connect or disconnect the external keyboard or mouse when the Panel PC is switched on. Switch off input power before connecting or disconnecting the keyboard or the mouse.

8.14 USB port

The USB controller is on board. Four USB type A connectors, compliant with rev. 2.0/1.1, are provided on the I/O panel.

A further USB connector is available on front panel covered by a little door (except for True Flat panel version)

The total max. current, for external USB devices, absorbed from the USB connectors must not exceed 0.5A for each connector. Furthermore the total power (5V) absorbed must be within the limit (for expansion devices) specified in the "Internal power supply" paragraph in this manual.

Refer to the motherboard user's manual for further information.

Notice

Use a cable 5m max long to connect an external USB device to an USB connector on the I/O panel.

Use a cable 4m max long to connect an external USB device to the USB connector on the front panel


8.15 Ethernet (LAN)

The Panel PC is equipped with two Gigabit Ethernet 10/100/1000 with RJ45 connectors on the I/O panel. The following are used.

- Intel 82577LM for LAN1
- Realtek RTL811C for LAN2 (see picture).

The WinXP device drivers for the Ethernet controllers are in the motherboard CD-ROM. Each controller has its specific driver.

Refer to the motherboard user's manual for further information.



8.16 Audio controller

The Panel PC is equipped with a Realtek ALC262 High Definition Audio controller. On the I/O panel there are 3 connectors (line out, line in e mic).

The WinXP device drivers are in the motherboard DVD.

Refer to the motherboard user's manual for further information.

8.17 Graphics controller

The Panel PC is equipped with an integrated graphics controller.

- Intel® Gen5.75 integrated graphics engine
- Display ports: DVI-I (CH7318), LVDS and VGA
- LVDS: Single Channel - 18/24-bit; Dual Channel: 36/48-bit
- Intel® Clear Video technology
- Intel® Dynamic Video Memory Technology (Intel® DVMT)
- Intel® Smart 2D Display Technology (Intel® S2DDT)

The graphics controller has three types of video interface for display.

1-LVDS interface for internal LCD panel (main display)

2-VGA interface for external CRT/LCD analog monitor (15 pin VGA).

3-DVI-D interface for external LCD digital monitor (24 pin DVI-D).

The Intel Graphics Drivers for WinXP/Win7 are in the motherboard DVD.

Refer to the motherboard user's manual for further information.

8.18 LCD display

The Panel PCs are equipped with TFT LCD as follow:

VX120P-QM57: 12.1" 1024x768 pixels 18 bit (single channel LVDS)

VX150P-QM57: 15" 1024x768 pixels 18 bit (single channel LVDS)

VX170P-QM57: 17" 1280x1024 pixels 48 bit (dual channel LVDS)

LCD	Active area / Pixel pitch (mm)	Brightness (typ.) 25°C (note1)	Contrast Ratio (CR) center(typ)	Viewing angle CR ≥ 10 (degree)	Backlight type / Backlight life (typ) 25°C (note2)
12.1"	245.76x184.32 0.240x0.240	500 cd/m ²	700:1	H 80/80 V 80/80	LED 50000 h
15"	304.12x228.09 0.297x0.297	400 cd/m ²	700:1	H 80/80 V 70/70	LED 50000 h
17"	337.92x270.33 0.264x0.264	350cd/m ²	1000:1	H 85/85 V 80/80	LED 50000 h

Note 1: values in the table are referred to a device working at least 15 minutes after power on.

I.P.S. Sistemi Programmabili reserves the right to change the LCD without notice to update the project.

Note 2: the typical lamp service life is defined as the time when the brightness becomes 50% of the original value (at 25°C)

Display of static images

The permanent display of a bright picture can lead to a burn in effect in the case of a TFT LCD. Shadows of the previous image could remain on the screen even changing the image. This is known as Temporary Image Retention (TIR) or Image sticking.

TIR doesn't affect LCD's life or reliability.

The best way to avoid TIR is to limit the amount of static content on the display.

When this is not an option, you can use a screensaver to display moving images (e.g. flying stars).

Display modes

The LCD has a fixed number of pixels so some video modes are supported in expansion mode.

Expansion mode is a function to expand the screen size in different resolutions (e.g. 800x600 on an 1024x768 LCD) so the image can be displayed almost fully on the screen.

In Expansion mode the display quality can look not very good in some cases.

Faulty pixels in LCD

A minimum number of faulty pixels are permissible.

The production process for TFT LCD does not currently guarantee that all pixels in the screen are error free. As long as it is not a case of an accumulation of locally faulty pixels, there are not relevant functional restrictions.

LCD panel selection by Bios Setup

LCD panel selection is by Bios Setup on the "Advanced – Video Function Configuration" menu.

VX120P-QM57 LCD Panel Type 3 : 1024x768 18 bit

VX150P-QM57 LCD Panel Type 3 : 1024x768 18 bit

VX170P-QM57 LCD Panel Type 13: 1280x1024 48 bit

Notice

We recommend you keep a note of the Setup settings. You will need to reset some settings if the battery that provides power for the CMOS RAM will get exhausted.

A keyboard is necessary to select/modify Bios Setup.

If you find problems on LCD panel running Bios setup, please temporary connect an external monitor on the VGA connector.

Read carefully the motherboard user's manual before to attempt to change BIOS Setup.

8.19 Touchscreen

The touchscreen is an order option.

Characteristics

Type:	8-wire analog resistive with antiglare surface
Light transmission:	80% (typ.)
Surface pencil Hardness:	3H (ASTM-D-3363-92A)
Controller:	TSHARC 12bit (RS232 serial interface 9600 baud to COM4).

Functional description

The analog resistive touchscreen is a sensor consisting of two opposing layers, each coated with a transparent resistive material, separated by a pattern of very small transparent insulating dots. Touching the top surface compresses the flexible top layer to the supported bottom layer causing electrical contact of the two layers between the span of insulating dots. Determining a touch location requires two measurements, one to obtain an X-axis coordinate and one to obtain a Y-axis coordinate. Applying a drive voltage across one layer produces a voltage on the other layer that can be measured using an A/D (Analog to Digital) converter. The touchscreen interface is made by a dedicated microcontroller. Touch point coordinates are reported to the Motherboard through the serial communication port (COM). The A/D converter used is a 12-bit type that can resolve up to 4096 different input values in each the horizontal and vertical direction. The analog resistive touchscreen used in the Panel PC is 8-wire type. This design compensates for resistance changes inherent to any touch system. Resistance changes are caused by ageing, use, temperature, and humidity.

The layers of the touchscreen are laminated to a chemically strengthened glass backing panel. The backing panel gives the layers rigidity and protects the display used behind the touchscreen.

The layers are made of polyester (PET) with the external side coated with an abrasion and chemical resistant anti-glare hard coat.

Use and care

The touchscreen assembled on the Panel PC is useful for use with fingers, gloves, pen tip, or other pointing device with rounded edge.

Caution

Avoid pressing the touchscreen with sharp pointing device. Permanent damage to the touchscreen can occur.

To maintain clear the front surface of the touchscreen, keep it free of dirt, dust, fingerprints, and other materials that could degrade optical properties. Cleaning the touchscreen surface regularly can do this.

See the “cleaning the display” paragraph later in this manual.

Long-term contact with abrasive or sharp materials will scratch the front surface, decreasing image quality.

UV Resistance

Not recommended for applications where touchscreen is exposed to direct sunlight for long periods of time.

Yellowness, brittleness and reduced adhesion on PET layers can occur.

Software drivers

The Panel PC is provided with software drivers for the touchscreen controller as well as utility functions. The software emulates much of the functionality of a standard mouse device, which is based on relative movement. Mouse motion is translated into a count of discrete movement steps for both the horizontal and vertical axis. The touchscreen mouse emulation is based on absolute movement. A touch will initiate both a cursor absolute movement and a mouse click event. Refer to the manuals provided on the CD-ROM for more information.

Software license agreement

The software drivers and utilities for the touchscreen are provided under a license agreement. The user must read the license agreement file on the CD-ROM before using the Panel PC.

Calibration

Calibration orients and aligns the touchscreen with the LCD display.

If the Panel PC is supplied with WinXP/Win7 OS installed on disk then the touchscreen is calibrated at the factory; if necessary re-calibration can be performed.

Refer to the manuals provided on the CD-ROM for more information about calibrating the touchscreen under Operating Systems.

An external mouse could be required to calibrate the touchscreen.

9 Maintenance

9.1 General

In normal use the Panel PC must be fitted with its back cover. The cover must be screw fastened to the chassis. During installation and maintenance operations the back cover can be opened by unscrewing the screws, which fasten it. Maintenance operations must only be performed by trained staff.



The Panel PC contains components, which are sensitive to electrostatic discharges (ESD).

Before working on the part inside the Panel PC the person performing the operation must discharge any static electricity by touching a metal part connected to the earth.

Perform work in a static safe environment.

Caution

Risk of damage.

Switch power input off and detach power plug before opening the Panel PC. 5Vsb could be active!

9.2 Spare parts

For spare parts please get in touch with I.P.S. service.

9.3 Replacing the motherboard

Caution

If the motherboard has to be replaced be sure that the proper BIOS Setup is installed otherwise damage or system fault may occur.

The motherboard is accessible by removing the back cover of the chassis.



To remove the motherboard:

- Switch power off and detach power cord.
- Remove any cable connected to the board. Keep a note of the cabling (wiring).
- Remove the riser card (unscrew the 2 locking screw)

- Remove the 4 screws securing the motherboard to the bottom of the chassis and the 2 nuts on the DVI-D connector (see picture).
- Remove and store the motherboard in an antistatic wrapper.

To install a new motherboard (of the same type as the replaced one):

- Set any jumpers as the replaced board (refer to the motherboard user's manual).
- Install the processor into its socket, the heatsink with fan cooler and the DRAM memory modules (follow motherboard user's manual instructions).
- Align the holes on the motherboard with the spacers on the bottom of the chassis and fasten the motherboard screws and the nuts on the DVI-D connector.
- Restore the cabling.
- Close the back cover.



9.4 Replacing the Compact Flash disk (CF)

The Panel PC supports one or two Compact Flash disks (as order option). A CF socket is available opening the little cover on the bottom side of the chassis. The second socket, if provided, is internal and it's available opening the cover. The CF must be inserted into the 50 pin socket placed on the adapter board.

Caution

The socket is polarized and CF insertion is one way only requiring a light strength. If the CF does not enter into the socket please do not force, probably you inserted the CF in the wrong way.

Notice

The CF to be inserted in the Panel PC must be Compact Flash 3.0 specification or previous. The CF must be max. IDE UDMA2 or PIO Mode 4.


To allow Windows XP booting the CF must be fixed disk type.



9.5 Replacing the 2,5" hard disk


To replace the 2.5" hard disk:

- Switch power off and detach power cord.
- Open the back cover.
- Keep a note of the cabling (wiring).
- Remove the cable from the hard disk.
- Unscrew the 4 screws securing the hard disk holder to the stand-offs. Remove completely the holder. Unscrew the four screws that lock the hard disk to the holder (see picture).
- Replace the hard disk and fix it to the holder with the 4 screws as before. Use original screws type. Different type of screws can damage it.
- Install the holder and lock it to the stand-offs.
- Connect the cable to the hard disk.
- Close and screw the back cover.
- Switch power on and check that the BIOS detect the new hard disk.
- Install the Operating System and all the software you need.



9.6 Replacing the power supply

- Switch power off then detach the power cord from the power supply.
- Open the back cover.
- Keep a note of the cabling (wiring).
- Detach power cables from devices inside the Panel PC.
- Unscrew the 4 screws securing the hard disk holder to the stand-off. and remove it.
- Remove the power supply, unscrewing the 2 screws on the cable side and the 2 screws on the I/O panel side of the chassis (see picture).
- Install a new power supply (use approved type only) and secure it to the chassis.
- Install the hard disk holder and lock it to the stand-off.
- Restore the cabling.
- Plug in the power cord then switch power on and check the system starts up.



9.7 Replacing the battery

Battery replacement must be performed only by authorized qualified personnel. A not rechargeable lithium battery on the motherboard provides power for the Real Time Clock (RTC) and CMOS Ram.

This battery has an estimate life expectancy of 20.000 hours (at 25°C).


Notice

When the battery loses power, BIOS Setup settings stored in CMOS RAM are cleared and the time and date is wrong. In such condition it could be required pressing the power button to switch power on.

The replacement battery must be a 3V 220mAh coin cell lithium type compatible with the Maxell CR2032 battery (**verify the exact type on the exhausted cell**).

Replacing the battery:

- Switch power off. Detach power cord. Open the back cover.
- Remove the battery (keep a note of the plus “+” side).
- Install the new battery with the plus “+” as the exhausted cell.
- Install any removed boards and close the back cover.
- You will need to set the system date and time and any settings different from default.



Warning

Danger of explosion and harmful material emission if lithium battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. The battery module contains lithium. Do not attempt to dispose of it in a fire or incinerator, do not overheat up to 80°C, do not short-circuit, do not invert poles, do not disassemble it: the battery may explode.

Don't try to recharge the lithium battery, the battery may explode.

Don't allow the battery to come in contact with water.

Always follow regulations in your area for lithium battery disposal...

9.8 Checking the CPU fan

On the CPU (processor) there is a heatsink with cooling fan.

Check the CPU fan frequently under normal conditions.

The fan can be checked with “hardware monitor” software supplied with the motherboard. This software can warn the operator if the fan speed is under a minimum threshold setup.

The heat sink + fan provided from the factory is a long life type, but if the temperature of the heatsink often rise over 70°C the lifetime of the fan can considerably drop.

Caution

The motherboard must work only with the (factory-approved) heatsink + cooling fan installed on the processor and well operating.

If the fan fails, it must be replaced with a factory-approved one.

To replace the heat-ink with fan cooler follow instructions on the motherboard user's manual.

9.9 Checking the Power Supply fan

Check the Power Supply fan.

If the fan fails, the whole power supply unit must be replaced.

9.10 Checking the chassis fan

Check the chassis fan.

If the fan fails, it must be replaced with a factory-approved one.

9.11 Cleaning the fan filter

Clean the chassis fan filter at least once a month under normal conditions. You may need to clean the filter more frequently if the Panel PC is located in an area with high levels of dust.

The Panel PCs has one fan filter (60x60mm. fan) on the upper side of the chassis.

To clean the fan filter:

- Switch the Panel PC off.
- Unscrew the filter retainer from the chassis. The filter pad can be removed (see picture)
- Replace the filter or (if you can't replace it) clean it with soap and water and allow drying before installing.
- Place the filter pad on the filter retainer.
- Hook the filter retainer on the chassis and secure it by the screw.



9.12 Cleaning the display

Switch power off and detach power cord before cleaning the Panel PC front panel.

Caution

Use of abrasive cleansers or solvents may damage the display window. Do not scrub or use brushes.

To clean the display window:

- Disconnect power from the Panel PC at the power source.
- For best results on touchscreen, use a clean, damp non-abrasive cloth and a standard glass cleaner but avoid products containing ammonia.

Caution

Spray the window cleaner on the cloth and not directly on Panel PC.

- Dry the display window with a chamois leather to avoid water spots.



Warning

Do not use alcohol or inflammables to clean the display window or any part of the Panel PC.

10 Troubleshooting

10.1 Troubleshooting procedure

To help identify and isolate a problem, we recommend the following procedure when a problem occurs:

1. Turn off the power to the Panel PC.
2. Disconnect any peripheral devices.
3. Monitor the Power On Self Test (POST) on the display. One of 3 events can occur:
 - The Panel PC will complete the boot process.
 - An error message will occur indicating a non-fatal error.
 - The boot process will terminate with a fatal error.
4. If the system boots, isolate the problem by connecting the peripheral devices one at a time until the problem occurs. If the problem is with a specific software package, you may want to re-install the software.
5. If there is a problem not related specifically to a software installation or peripheral device, refer to the following troubleshooting checklist.

10.2 Troubleshooting check list

The system does not display any message:

- ✓ Check if the power LED on the front panel is illuminated. If not check the power supply. Try pushing power button (soft power).
- ✓ Check if all the connections between the Motherboard, the power supply and the front panel are firmly inserted.
- ✓ Check if the RAM module is firmly inserted in the socket.
- ✓ Check if the speaker beeps during Power On Self-Test. If not, probably there is a fault in the Motherboard.

If there is a problem during boot:

- ✓ Are all connections secured?
- ✓ Are the device drivers installed?
- ✓ Is the Operating System properly installed on the hard disk drive?
- ✓ Did your hard disk loose a file? Run Scandisk to check for clusters or open files.
- ✓ Is BIOS properly configured? Refer to the motherboard user's manual.

If there is a problem after boot:

- ✓ If the problem is intermittent, you may have a loose connection. Check all connections including any add-on cards. Check that the memory modules (DIMM) are fully installed.
- ✓ Does your system have a virus? Run anti-virus software.
- ✓ Did your hard disk lose a file? Run Scandisk to check for clusters or open files.
- ✓ If you are running a software package, try to re-install the software.
- ✓ Although the Panel PC has a protected power supply, a transient voltage in the power line or peripheral cable may cause unexpected reboots or a locked up system. If so exit the application and start over. Check cabling and grounding.
- ✓ Is the system overheating? Verify that the CPU fan and the power supply fan work.

If there is a problem running new software:

- ✓ Does the software have a hardware requirement that is not present?
- ✓ Are you using an authorized copy of the software? Some items of software will not work.
- ✓ Did the software install correctly? Re-install the software.
- ✓ Are you following the software's instructions? Refer to the software manual.

The system loses time and date after power off:

The battery on the motherboard is probably exhausted. Replace the battery as indicated in paragraph "Replacing the battery".

If you have verified the CHECK LIST troubleshooting and the problem is still present, contact I.P.S. follow the indications suggested in "Procedure for repairing the products" paragraph.

11 Decommissioning

11.1 Disposal



When this crossed-out wheeled bin symbol is attached to a product it means this equipment must not be disposed as urban waste but it must be separated and collected as laws and order in force about waste electrical and electronic equipment (WEEE).

Because of the substances present in the equipment, improper use or disposal can cause damage to human health and to the environment.

The correct disposal of the old appliance will help prevent potential negative consequences for the environment and human health.

For more detailed recycling information contact your local waste collection body. In case of illicit disposal, sanctions will be levied on transgressors.

Notes